



Instructions for fitting the rubber mat to the Escargoline

Tools required: hammer, pencil, large screwdriver, 12 mm spanner, small piece of wood

PIECES	Nb
Rubber mat	
1 triangular piece	1
1 rectangular piece	1
Metal part	
Small piece of pipe as a cookie cutter	1
Hardware	
Plastic screw with nut	9

Please check that the parcel contains all the parts listed opposite.

1

Place the 2 pieces of carpet on the Escargoline



2

Using a pencil, mark the 9 positions for the plastic screws on the underside as shown in the sketch.



3

Remove the 2 rubber pieces to make drilling easier.

Place the piece of rubber on the piece of wood and tap it with the hammer and punch.

4

Reposition the carpet on the Escargoline.

Fix the 9 screws with the nut underneath. Secure the screw with the large screwdriver and tighten the nut with a Ø 13 spanner.

To avoid losing the nut, put a dot of office glue in it. Even with the glue, the nut will remain removable.

